

of the deck load and the inside of the bulwark or rail, a pendant or other alternate device shall be provided to allow trimming of the gear and to prevent employees from going over the side.

[62 FR 40202, July 25, 1997, as amended at 65 FR 40945, June 30, 2000]

**§ 1918.55 Cranes (See also § 1918.11).**

The following requirements shall apply to the use of cranes forming part of a vessel's permanent equipment.

(a) *Defects.* Cranes with a visible or known defect that affects safe operation shall not be used. Defects shall be reported immediately to the officer in charge of the vessel.

(b) *Operator's station.* (1) Cranes with missing, broken, cracked, scratched, or dirty glass (or equivalent) that impairs operator visibility shall not be used.

(2) Clothing, tools and equipment shall be stored so as not to interfere with access, operation or the operator's view.

(c) *Cargo operations.* (1) Accessible areas within the swing radius of the body of a revolving crane or within the travel of a shipboard gantry crane shall be physically guarded or other equally effective means shall be taken during operations to prevent an employee from being caught between the body of the crane and any fixed structure, or between parts of the crane. Verbal warnings to employees to avoid the dangerous area do not meet this requirement.

(2) Limit switch bypass systems shall be secured during all cargo operations. Such bypass systems shall not be used except in an emergency or during non-cargo handling operations such as stowing cranes or derricks or performing repairs. Any time a bypass system is used, it shall be done only under the direction of an officer of the vessel.

(3) Under all operating conditions, at least three full turns of rope shall remain on ungrooved drums, and two full turns on grooved drums.

(4) Crane brakes shall be monitored during use. If crane brakes are unable to hold the load, the crane shall not be used.

(5) Cranes shall not be used if control levers operate with excessive friction or excessive play.

(6) When cranes are equipped with power down capability, there shall be no free fall of the gear when a load is attached.

(7) When two or more cranes hoist a load in unison, a designated person shall direct the operation and instruct personnel in positioning, rigging of the gear and movements to be made.

(d) *Unattended cranes.* When cranes are left unattended between work periods, § 1918.66(b) (4)(i) through (v) shall apply.

**Subpart G—Cargo Handling Gear and Equipment Other Than Ship's Gear**

**§ 1918.61 General (See also appendix IV of this part).**

(a) *Employer provided gear inspection.* All gear and equipment provided by the employer shall be inspected by the employer or designated person before each use and, when appropriate, at intervals during its use, to ensure that it is safe. Any gear that is found upon such inspection to be unsafe shall not be used until it is made safe.

(b) *Safe working load.* (1) The safe working load of gear as specified in §§ 1918.61 through 1918.66 shall not be exceeded.

(2) All cargo handling gear provided by the employer with a safe working load greater than five short tons (10,000 lbs. or 4.54 metric tons) shall have its safe working load plainly marked on it.

(c) *Gear weight markings.* The weight shall be plainly marked on any article of stevedoring gear hoisted by ship's gear and weighing more than 2,000 lbs. (.91 metric tons).

(d) *Certification.* The employer shall not use any material handling device listed in paragraphs (f) and (g) of this section until the device has been certificated, as evidenced by current and valid documents attesting to compliance with the requirements of paragraph (e) of this section.

(e) *Certification procedures.* Each certification required by this section shall be performed in accordance with part 1919 of this chapter, by a person then